



## **INSTALLATION INFORMATION FOR: LOW MOUNT ALTERNATOR BRACKET - PART # 8990**

### ***INSTALLATION INSTRUCTIONS***

Install alternator to bracket using the two outermost holes in the bracket.

Install alternator and bracket to the block as a unit using the two bottom bolt holes below the front freeze plug on the drivers side of the engine block.

Note: This bracket fits Small Block Chevy V8 engines with SHORT WATER PUMP only.

